

## ***PLEASE READ BEFORE INSTALLING***

*Thank you* for selecting our TENSION SCREW UPGRADE KIT. To ensure many hours of use we are including some installation tips.

### INSTALLATION:

Kits includes; two threaded screws. Two delrin shoulder plugs, and four compression washers.

Put two of the compression washer together. Notice the washers are shaped like little dinner plates. Place the edge of the plates together so that the bottoms of the dinner plates are away from each other. This way they become a little spring. Put a light coating of a lubricant on the button part of the plugs and also on the shafts. We suggest any type of a paste base lubricant. Now install the compression washer pairs on the shafts of the delrin plugs and insert the delrin plugs into the tension screws. Screw these assemblies into the "Farley" rest after removing the original tension screws.

### ADJUSTMENT PROCEDURE:

Snug both screws so that there is some resistance to movement of the joystick. Check by moving the joystick side to side, up and down, and radially. Increase the tension of both screws equally so that a downward force of approximately 9 to 11 pounds, or as required to support you gun, is required to cause the bag plate to move without using the joystick. If the screws don't have equal tension, one side of the bag plate will move before the other. Check by moving the joystick side to side, up and down, and radially. Readjust until the bag plate moves as desired. Just a little rotation of the tension screws will make big changes in the action of the bag plate. Adjust carefully.

*Go shoot small groups and enjoy!*

***S.E.&A.***

***Shadetree Engineering & Accuracy***

***ShadetreeEA.com***

110614/1100